ice>Link: Plus Update Guide

1. Update Contents



a. Copy the "ice-Link_Plus_fw_xxx.exe" self extracting archive into a folder. Start the extraction by double clicking the file. A window, as shown in the image above, will open, showing the extraction process. For Mac ZIP format is also available.


2. Copying the Update Files




a. Connect the iPod to the computer. If you get the message shown above select Cancel or all the information will be permanently deleted from your iPod. This message appears when an iPod is formatted for Mac and is connected to a PC or vice versa.



b. If you are connecting an iPod to a computer that is not the default iTunes music library you will see the warning message shown in the image above. Select NO or all songs will be permanently deleted from the iPod.




c. Open iTunes. Go to Edit > Preferences... Click the iPod tab. Make sure you have "Manually manage songs and playlists" selected as shown in the image above.



d. Open the folder to which the update files were extracted to. From the window containing the update files, DRAG the file named "UPDATE.M3U" to the location shown in the picture above.



e. A window as shown in the image above, will pop up indicating the playlist copy progress.



f. A new playlist named "UPDATE" will appear in iTunes. Select this playlist and then select all of the files within the playlist. DRAG the selected files into the iPod icon as shown in the image above.

If the file transfer has been completed, the update files have successfully been copied to the iPod. The iPod may now be disconnected from your computer, and you may proceed to the following steps.

3. The Update Process

Connect the iPod to the ice>Link for the rest of the update process.

a. <u>ice>link Setup 3/7</u>

Rnd Key Random

Update ice>link

About ice>link

In the ice>ink menu select ice>Link Setup and then select Update ice>Link.

b. Update ice>link 2.01
Update found,
version 2.02
Load update?

An update found screen will appear as shown in the image above. It will ask for a Load Update confirmation. Select to confirm.

c. Update ice>link 2.01
Loading update,
don't disconnect
iPod (~5 min.)

A Loading Update screen will appear as shown in the image above. *DO NOT DISCONNECT the iPod at this time as it may cause permanent damage to the ice>Link*. The update will take about 1 minute on a 4G iPod, while it will take over 3 minutes on a mini iPod. You can continue to listen to your music while updating. You will notice that the track counter goes from 0 to 99 as an indication of the upgrade process. Ice>Link Plus will restart itself a few seconds after reaching 99.

d. Config 2.01
Panasonic
config selected.
Please turn ignition
off and on again.
Select CD changer!

When the Update is complete the ice>Link will reboot. Following the directions on the screen (as shown in the picture above), turn the ignition OFF and then ON and select the CD changer source. The update process is now complete.

4. SUPPORT

If you experience any problems while updating, check Knowledge Base at support.dension.com or send email to support@dension.com for technical support support@densionusa.com for US or Canada).